



AV Connectivity, Distribution  
And Beyond...

**VIDEO WALLS VIDEO PROCESSORS**  
**VIDEO MATRIX SWITCHES**  
**EXTENDERS SPLITTERS WIRELESS**  
**CABLES & ACCESSORIES**

## VGA / Audio Extender Single CAT5 / CAT6 with RGB Delay Control & EQ



**Model #: VGA-C5A-R**



© 2010 Avenview Inc. All rights reserved.

The contents of this document are provided in connection with Avenview Inc. ("Avenview") products. Avenview makes no representations or warranties with respect to the accuracy or completeness of the contents of this publication and reserves the right to make changes to specifications and product descriptions at any time without notice. No license, whether express, implied, or otherwise, to any intellectual property rights is granted by this publication. Except as set forth in Avenview Standard Terms and Conditions of Sale, Avenview assumes no liability whatsoever, and disclaims any express or implied warranty, relating to its products of Avenview Inc. is strictly prohibited.



## TABLE OF CONTENTS

SECTION 1: GETTING STARTED.....	3
1.1  IMPORTANT SAFEGUARDS .....	3
1.2  SAFETY INSTRUCTIONS .....	3
1.3  REGULATORY NOTICES FEDERAL COMMUNICATIONS COMMISSION (FCC) .....	4
2.    INTRODUCTION.....	5
2.1  PACKAGE CONTENTS.....	5
2.2  BEFORE INSTALLATION .....	6
3.    PANEL DESCRIPTION .....	7
4.    INSTALLATION .....	8
5.    GENERAL TROUBLESHOOTING .....	8
SECTION 2: SPECIFICATIONS .....	9

## TECHNICAL SUPPORT

### CONTACT US



Phone: 1 (866) 508 0269



Email: [support@avenview.com](mailto:support@avenview.com)



USA Head Office Avenview Corp. 275 Woodward Avenue Kenmore, NY 14217



## SECTION I: GETTING STARTED

### I.1 IMPORTANT SAFEGUARDS

Please read all of these instructions carefully before you use the device. Save this manual for future reference.

#### What the warranty does not cover

- Any product, on which the serial number has been defaced, modified or removed.
- Damage, deterioration or malfunction resulting from:
  - Accident, misuse, neglect, fire, water, lightning, or other acts of nature, unauthorized product modification, or failure to follow instructions supplied with the product.
  - Repair or attempted repair by anyone not authorized by us.
  - Any damage of the product due to shipment.
  - Removal or installation of the product.
  - Causes external to the product, such as electric power fluctuation or failure.
  - Use of supplies or parts not meeting our specifications.
  - Normal wear and tear.
  - Any other causes which does not relate to a product defect.
- Removal, installation, and set-up service charges.

### I.2 SAFETY INSTRUCTIONS




The Avenview VGA-C5A-R, VGA and Audio Extender over Single CAT5/CAT6 with RGB Delay Control has been tested for conformance to safety regulations and requirements, and has been certified for international use. However, like all electronic equipments, the VGA-C5A-SET should be used with care. Read the following safety instructions to protect yourself from possible injury and to minimize the risk of damage to the unit.

- ⚠ Do not dismantle the housing or modify the module.
- ⚠ Dismantling the housing or modifying the module may result in electrical shock or burn.
- ⚠ Refer all servicing to qualified service personnel.
- ⚠ Do not attempt to service this product yourself as opening or removing housing may expose you to dangerous voltage or other hazards
- ⚠ Keep the module away from liquids.
- ⚠ Spillage into the housing may result in fire, electrical shock, or equipment damage. If an object or liquid falls or spills on to the housing, unplug the module immediately.
- ⚠ Have the module checked by a qualified service engineer before using it again.
- ⚠ Do not use liquid or aerosol cleaners to clean this unit. Always unplug the power to the device before cleaning.



## I.3 REGULATORY NOTICES FEDERAL COMMUNICATIONS COMMISSION (FCC)

This equipment has been tested and found to comply with Part 15 of the FCC rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. Any changes or modifications made to this equipment may void the user's authority to operate this equipment.

Warning symbols	Description
	<p>ONLY USE THE PROVIDED POWER CABLE OR POWER ADAPTER SUPPLIED. DO NOT TAMPER WITH THE ELECTRICAL PARTS. THIS MAY RESULT IN ELECTRICAL SHOCK OR BURN.</p>
	<p>DO NOT TAMPER WITH THE UNIT. DOING SO WILL VOID THE WARRANTY AND CONTINUED USE OF THE PRODUCT.</p>
	<p>THE VIDEO BOARDS ARE VERY SENSITIVE TO STATIC. PLEASE ENSURE IF RACK MOUNTED OR INSTALLED ON A SURFACE, IT SHOULD BE IN A GROUNDED ENVIROMENT.</p>

	<p><b>⚠ WARNING</b></p> <p>Read &amp; understand user guide before using this device.</p> <p>Failure to follow the proper installation instructions could result in damage to the product and preventing expected results.</p>
---	--



## 2. INTRODUCTION

With only one cost effective CAT-5e cable, the Avenview VGA-C5A-R lets you extend VGA (WUXGA) to cover the distance up to 300m (1,000ft). With built-in EQ and GAIN control, the transmission path can be adjusted to adapt the cable quality and video bandwidth. Furthermore, the VGA RGB delay control [de-skew] function provides the compensation among R, G, B signals due to long transmission or through normal LAN cable. Analog stereo audio signals can be sent along with high quality VGA signal over long distance LAN cable. Compatible with the VGA-C5-SP8

- Supports up to WUXGA (1920x1200@60) to 300m (1,000ft)
- Supports Analog Stereo Audio and S/PDIF Digital Audio
- Adjustable equalization and gain control on Receiver unit
- De-skew compensation available for RGB delay control
- Wall mounting case for better fixedness

### 2.1 PACKAGE CONTENTS


Before you start the installation of the converter, please check the package contents.

1	- VGA-C5A-R x 1	
1	Power Adapter (+5VDC)	
1	User's Manual	



## 2.2 BEFORE INSTALLATION

- Put the product in an even and stable location. If the product falls down or drops, it may cause an injury or malfunction.
- Don't place the product in too high temperature (over 50°C), too low temperature (under 0°C) or high humidity.
- Use the DC power adapter with correct specifications. If inappropriate power supply is used then it may cause a fire.
- Do not twist or pull by force ends of the optical cable. It can cause malfunction.



### 3. PANEL DESCRIPTION

#### INPUT PANEL (Receiver, VGA-C5A-R)



1. 5V 2A DC Power Connector	2. RJ45 IN for CAT5 cable
3. EQ: Rotary Control for equalization of R, G, B respectively	4. GAIN: Rotary control for Gain Control of R, G, B respectively
5. Rotary Control: R=0~2, G=3~5, B=6~7 for de-skew compensation on respective color channel	6. Push button to increase level of de-skew compensation
7. Push button to decrease level of de-skew compensation	

#### OUTPUT PANEL (Receiver, VGA-C5A-R)



1. Audio OUT	2. S/PDIF OUT
3. VGA OUT	





## 4. INSTALLATION

1. Connect VGA and audio source to Transmitter (VGA-C5-SP8)
2. Connect VGA display and speakers to Receiver (VGA-C5A-R)
3. Connect CAT5/CAT6 cable between Transmitter (VGA-C5-SP8) and Receiver (VGA-C5A-R)
4. Ensure that cables are tightly connected
5. Plug in 5V 2ADC power adapter to the power jack of the Receiver VGA-C5A-R.
6. Plug in 5V 4ADC power adapter to the power jack of the Transmitter VGA-C5-SP8.

## 5. GENERAL TROUBLESHOOTING

PROBLEM	POSSIBLE SOLUTION
<b>NO IMAGE</b>	<ul style="list-style-type: none"><li>• Check if connection to the source and the display are correct.</li><li>• Ensure that display device supports the resolution that is being output.</li></ul>
<b>SCREEN DEFECTS APPEAR</b>	<ul style="list-style-type: none"><li>• This product supports up to WUXGA (1920x1200) resolution.</li><li>• Check the VGA and CAT5 connection</li><li>• If outputting from a PC. Check the maximum resolution range of the graphics card.</li></ul>

1. *If a blurred video is seen or even worse, not displayed at all, try to adjust the EQ and Gain rotary controls to improve the cable skew. GAIN rotary controls are designed for gain control, and EQ rotary controls are designed for equalizing the wave form of the receiving video signal. It is suggested to begin with adjusting the rotary control of EQ to get the input video displayed first, and then the GAIN according to the video you see on the screen.*
2. *RGB delay control [De-skew] offers the flexible functionality to allow skew compensation among VGA R, G, B signals due to long transmission or thru low quality cable. By adjusting the rotary switch to choose R, G or B color channel at first, then use the push buttons to increase or decrease the delay in the corresponding color channel. There are totally 31 steps, each step with 2ns difference, for adjusting the delay between each color individually. Then the graphics quality can be further assured.*





## SECTION 2: SPECIFICATIONS

ITEM	DESCRIPTION	
Units		<b>VGA-C5A-R</b>
Unit Description		VGA Receiver with RGB Delay Control
Video Bandwidth	350MHz	
Video Support	VESA	
Supported Resolutions	Up to WUXGA (1920 x1200)	
Resolution and Distance	WUXGA 1920x 1200 at 300 meters (1000 feet)	
Audio Support	Stereo	
Equalization	Continuous Analog Control	
Input Video Signal	1.2 Volts (peak-to-peak)	
RGB Delay Control	-	Yes
ESD Protection	<ul style="list-style-type: none"> <li>- Human body — ±19kV (air-gap discharge) &amp; ±12kV (contact discharge)</li> <li>- Core chipset — ±8kV</li> </ul>	
Input		1 x RJ45
Output		1 x VGA 1 x 3.5mm + 1 x RCA
VGA Connector	HD-15 (15 pin D-sub Female)	
RJ45 Connector	WE/SS 8P8C with 2 LED indicators	
3.5mm Audio Connector	Earphone jack for Analog Stereo Audio or IR Cable	
RCA Connector	S/PDIF Digital Audio	
Dimensions (L x W x H)	4.8" x 3.7" x 1"	
Power Supply	5V 2A DC	
Power Consumption	5 Watt (max)	

### *Environmental*

Operating Temperature	32° ~ 104°F (0° to 40°C)
Storage Temperature	-4° ~ 140°F (-20° ~ 60°C)
Relative Humidity	20~90% RH (no condensation)



### Disclaimer

While every precaution has been taken in the preparation of this document, Avenview Inc. assumes no liability with respect to the operation or use of Avenview hardware, software or other products and documentation described herein, for any act or omission of Avenview concerning such products or this documentation, for any interruption of service, loss or interruption of business, loss of anticipatory profits, or for punitive, incidental or consequential damages in connection with the furnishing, performance, or use of the Avenview hardware, software, or other products and documentation provided herein.

Avenview Inc. reserves the right to make changes without further notice to a product or system described herein to improve reliability, function or design. With respect to Avenview products which this document relates, Avenview disclaims all express or implied warranties regarding such products, including but not limited to, the implied warranties of merchantability, fitness for a particular purpose, and non-infringement.

